



StyleCamDeluxe

Digital Camera & Digital Video Camera

Owner's Manual

About This Manual

For Customers in the U.S.

FCC Statement

This device complies with 15 the FCC Rules. Operation is subject to the following two conditions: (i) This device may not cause harmful interference, and (ii) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION

This equipment has been tested and found to comply with limits for a Class B digital device. Pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. The equipment generates, use, and can radiate radio frequency energy and if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

You are cautioned that any changes or modifications not expressly approved in this manual could void your warranty.

For Customer in Canada

CAUTION

This class B digital apparatus complies with Canadian ICES-003.

Notes on Copyright

Images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner, unless intended only for personal use. Note that some restrictions apply to the photographing of stage performances, entertainments and exhibits, even when intended purely for personal use. Users are also asked to note that the transfer of memory cards containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

Liquid Crystal

If the glass on the LCD status display becomes cracked or broken please take particular care

with the liquid crystal inside the display. If any of the following events occur, take action as indicated.

- If liquid crystal comes from in contact with your skin
Wipe the area with a cloth and then wash thoroughly with running water and soap.
- If liquid crystal gets into your eyes
Flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- If liquid crystal is swallowed
Flush your mouth thoroughly with water. Drink large quantities of water and induce vomiting. Then seek medical assistance.

Notes on Electrical Interference

If the camera is used in hospitals or aircrafts, please note that it may cause interference with other equipment in the hospital or aircraft.

For details, please check with the applicable regulation in that area.


Trademark Information

© 2002 Foxlink Peripherals, Inc. StyleCam is a trademark of Foxlink Peripherals, Inc. SiPix is registered by SiPix Group Ltd. and used under license. MS-DOS and Windows are registered trademarks of the Microsoft Corporation registered in the USA and other countries. Windows is an abbreviated term referring to the Microsoft Windows Operation System. Other company or product names are trademarks or registered trademarks of their respective companies.

Table of Contents

Getting to Know Your Camera.....	1
Selecting Power Supply.....	2
Installing Software.....	3
- StyleCam Deluxe Installer Menu	
- Installing ArcSoft PhotoImpression	
- Installing ArcSoft VideoImpression	
- Installing Adobe Acrobat Reader	
- Installing StyleCam Deluxe Driver	
- Connecting StyleCam Deluxe to Your PC	
Learning About the LCD Display.....	12
- Status LCD: Icon Description	
- Resolution Settings/Mode	
Taking Pictures & Deleting Pictures.....	13
- Using the Flash	
- Using the Self-timer	
- Deleting Pictures	
Recording Movie with the Video & Audio Mode.....	16
Downloading Still Images & Videos.....	17
Uninstalling Software.....	20
Camera Maintenance.....	21
Troubleshooting.....	22
Product Specification.....	24
One Year Limited Warranty – USA & Canada	25
Warranty Service – USA & Canada.....	26
Technical Support – USA & Canada.....	27
Technical Support & Warranty – EUROPE.....	28
Technical Support & Warranty – ASIA PACIFIC.....	29

Getting to Know Your Camera



Selecting Power Supply

The StyleCam Deluxe uses two (2) AA-size alkaline. Do not use rechargeable batteries. Using rechargeable batteries may damage the camera and will void warranty. Please read the important notes and battery information below before inserting batteries into your digital camera.

Important Battery Information

- All images will be lost if the camera is not supported with enough battery power.
- Download all images as soon as possible to avoid losing or damaging the images. The images are saved on the camera's SDRAM, this uses the battery's power even after the camera's power is turned off. We suggest that you download the images within 24 hours to avoid losing the pictures. The time may vary depending on how many pictures and how many videos are saved on the camera, as well as the quality of the batteries used.
- Remove batteries before storing camera or when not in use for an extended period.
- Do not use different brands or different types of batteries together.
- Do not use rechargeable batteries.
- Do not use new and used batteries together.
- Always turn the camera's power to OFF when replacing the batteries.
- Do not remove the batteries from the battery compartment while connecting with PC. Otherwise, You may need to push the camera reset access button once the camera can't power-up. If you reset the button, images will be lost.

Inserting Batteries

1. Open the Battery Compartment Cover (shown below) located on the bottom of your StyleCam Deluxe.



2. Take two (2) fresh AA alkaline batteries of the same brand and insert them into the battery compartment. When inserting, make sure that you follow the polarity directions (+) (-), as indicated on the side of the battery cover.
3. Press down the battery cover to lock the battery door.

Note: *The StyleCam Deluxe allows up to 1 minute for changing batteries without losing images saved on the camera. If the time exceeds 1 minute, the camera may not power-up immediately. In this case, you will need to reset the camera. To reset the camera, insert a paper clip into the reset access to press the RESET button, and then release. Wait two (2) seconds for the green*

LED light to flash once, at this point the camera should function normally.

Installing Software

The StyleCam Deluxe includes the following software and applications: StyleCam Deluxe TWAIN driver - to transfer pictures/video from the camera to the computer, ArcSoft PhotoImpression 3.0 – for photo editing, VideoImpression 1.6 - for video editing & capturing live video, and Adobe Acrobat Reader - to access the Owner's Manual (PDF).

Before installing the provided software, please check the PC-Requirement list below to ensure that your computer is compatible with the supplied software.

Table 3 - PC Requirement Checklist

Operating System	Windows 98SE/ 2000/ME/XP
CPU	Pentium processor or higher
RAM	64MB RAM or higher
Hard Disk Space	90MB (for 98se/Me) 128MB (for 2000/XP)
USB interface	USB port
CD installation	CD-ROM drive
Monitor	16-bit color VGA display

Important Notes:

- Due to varying compatibility among USB HUBS, compatibility is not guaranteed.
- Due to varying compatibility among USB interface cards, compatibility is not guaranteed.

Installing the StyleCam Deluxe Software

Insert the StyleCam Deluxe CD into your CD-ROM drive. The CD should auto run. Otherwise, go to **Start → Run** and type "D:\setup.exe" (where D:\ is your CD-ROM drive). The following screen will appear on your monitor.



You have two options: *Automatic Installation* or *Custom Installation*. Please check one of the selections and click “Continue” located in the bottom right corner.

Automatic Installation (Recommended)

By default the “Automatic Installation” is checked. Click “Continue” to install the camera software.



Note: the grayed-out item(s) are programs that are already installed on your computer, and you do not need to install them again.

1. The license agreement for the ArcSoft PhotoImpression and VideoImpression will appear. Click “Yes” to accept the terms of your agreement with ArcSoft. The installation of each of these programs will take up to 5 minutes to complete.
2. After the ArcSoft programs install, Adobe Acrobat Reader will begin to install.
Note for Windows 98SE users ONLY: You will be prompted to reboot at the end of this installer, please choose “Reboot Later” to finish installing all the software.
3. The license agreement for the StyleCam Deluxe Driver will appear, click “Yes” to accept the terms of the agreement to continue installation.

4. When the installation is completed, the computer will prompt you to reboot your system. Please choose “Reboot now” and click “Finish” to reboot your computer.

Note: Please save your work and close all programs before rebooting your computer

For Windows 98SE users ONLY:


You may encounter an error message during installation due to old version of DirectX installed on the computer. Please select “Yes” and continue with installation.

Custom Installation

Select “Custom Installation” from the Installer Menu shown here, and click “Continue” to install the software.




On the next screen, please check the items that you want to install on your computer, and click “Continue” to precede with installation. *Note:* the grayed-out item(s) are programs that are already installed on your computer, and you do not need to install them again.




Installing ArcSoft PhotoImpression

Please follow the instruction below to install ArcSoft PhotoImpression.

1. Select the language you want to install from the drop down list.




2. On the welcome screen, click “Next” to continue setup.




3. On the license agreement screen, click “Yes” to accept license agreement to continue setup.



4. Chose the destination location of where you'd like to install the software and click “Next”.




5. Select the components that you want to install and click “Next”




6. Click "Next" on the select program folder screen.



7. The setup progress bar will appear, please wait until the bar disappears to proceed.




8. Click "Finish" to complete setup. (For Windows 98se ONLY: You will be prompted to remove the CD from CD-ROM drive and reboot your computer. Please keep the CD inside the CD-ROM drive, select "Reboot later", and continue installing the other applications before restarting your system.)




Installing ArcSoft VideoImpression

Please follow the instruction below to install ArcSoft VideoImpression software on your computer.


1. On the welcome screen, click "Next" to continue setup.




2. Click “Yes” to accept the license agreement to continue setup.




3. Click “Next” on the choose destination location screen.




4. Click “Next” on the select program folder screen to continue setup.



5. A setup status bar will appear, please wait until the screen disappears to continue.




6. Click “Finish” to complete setup VideoImpression. (For Windows 98se ONLY: You will be prompted to remove the CD from the CD-ROM drive and reboot your computer. Please keep the CD inside the CD-ROM drive, select “Reboot Later”, and continue installing the other applications before restarting your system.)




Installing Adobe Acrobat Reader


Please follow the instructions below to install Adobe Acrobat Reader. The setup status bar will appear, please wait until the bar disappears to continue setup.



1. Click “Next” on the welcome screen to continue setup.



2. Click “Next” on the destination folder.




3. Click “OK” to complete setup. (For Windows 98se ONLY: You will be prompted to remove the CD from the CD-ROM drive and to reboot your computer. Please keep the CD inside the CD-ROM drive, select “Reboot Later”, and continue installing the other applications before restarting your system.)




Installing StyleCam Deluxe TWAIN Driver

Please follow the instructions below to install the StyleCam Deluxe TWAIN driver.


On the welcome screen, click “Next” to continue setup.




1. Click “Yes” to accept the license agreement to continue installation.




2. A setup status bar will appear, please wait until the screen disappears to continue to the next step.



3. You may run into a message from Microsoft that requires “Digital Signature” on the driver. It is safe to ignore this message, and click “Yes” to complete setup.




4. On the setup complete screen, select “Yes, I want to restart my computer” and click “Finish”.



Note: Please **save** and **close** all running programs so that you do not lose any important document.

Connecting the StyleCam Deluxe to Your PC

Before downloading any images or video, you must connect the StyleCam Deluxe to your computer with the supplied USB cable. Please make sure that the StyleCam Deluxe CD is inserted in the CD-ROM drive the first time you plug the camera to the computer. Also, we recommend that there are no image or video saved on the StyleCam Deluxe. Please follow the instructions below to connect your camera to your computer. (**Note:** Do not connect the USB cable until after installing the bundled software).

1. Plug the smaller USB connector to your StyleCam Deluxe USB port (located on the right side of the camera).
2. Plug the larger USB connector to the USB port on the back of your computer.
3. The StyleCam Deluxe is BUS-powered, so once it's connected to the computer, it will automatically power on, and the status LCD will display the  icon to indicate that it

is now connected to your PC.

4. The computer will detect a new hardware device and prompt you to install the StyleCam Deluxe Drivers (Video & Still).
5. Follow the on screen instructions to complete installing the StyleCam Deluxe still image & video drivers.

Note: You must keep the CD inside the CD-ROM drive during the first time that you connect your StyleCam Deluxe camera to your computer










If you encounter a *Digital Signature* message from Microsoft, it is OK to ignore this message and click "Continue". Clicking "Continue" will not harm your computer in any way.

Using the StyleCam Deluxe

Learning About the LCD Display

The StyleCam Deluxe LCD status display shows the camera setting information, the resolution mode, flash mode, number of pictures taken, and so on. Please refer to the Table 1 below for icon explanation shown in the LCD status.

Table 1 – Camera Icon & Description

Icon	Description
	Indicates capture mode for digital still images
	Indicates movie mode is enabled Movie mode: 320 x 240, up to 60 seconds of video
	Indicates audio mode is enabled Audio mode: Up to 50 minutes of audio
	Automatic flash: Flash is turned on, and it will occur automatically <i>Note:</i> The icon will blink for 5 seconds, please wait until the icon stops blinking and then take a picture.
	Indicates the picture quality setting (16MB internal memory) Three Stars: 1280 x 1024, 9 still images Two Stars: 1280 x 1024, 32 still images One Star: 640 x 512, 144 still images
	Self-timer function is enabled (10 seconds)
	Indicates the battery charge level
	Indicates the number of pictures taken
	USB connection to PC

Warning Signals

Low battery warning

When your StyleCam Deluxe is at full power, the battery indicator on the LCD display will be fully shown. When power is low, the icon will flash. This indicates that the batteries are weak and need to be replaced.

Note: The StyleCam Deluxe allows one (1) minute to change the batteries without losing all the images saved on the camera. If possible, we recommend that you download all images to your computer before changing batteries.

Full memory warning



When your StyleCam Deluxe's memory is full, the USB indicator and all icons on the LCD will flash together.

Taking Pictures & Deleting Pictures

Before taking pictures with StyleCam Deluxe, make sure that the battery has sufficient power. Check the battery indicator on the status LCD for battery power level. Please follow the instructions below to take pictures with the StyleCam Deluxe.


1. Turn on your StyleCam Deluxe by pressing the Power/Mode button. Your camera's status LCD will display camera information such as resolution (refer to Table 2), capture mode, flash, etc.
2. Use the Power/Mode button to select your desired setting. (E.g. capture mode with two stars).
3. Find your subject by looking through the viewfinder.
4. Hold still and press the shutter button firmly to take the picture.
5. When you release the shutter button, you'll hear a beep sound to confirm the picture has been taken.

Table 2 – Resolution Settings


Mode	Resolution	Level of compression
Three stars	1280 x 1024	Uncompressed
Two stars	1280 x 1024	1/6 compression
One Star	640 x 512	1/4 compression
Movie mode 	320 x 240	1/8 compression
Self-timer mode 	1280 x 1024	1/6 compression

Taking a picture with the flash

When the red LED is on, there is insufficient light for the camera to take a good picture without using the flash. If the StyleCam Deluxe is in auto flash mode, the flash will fire automatically when the shutter button is pressed.



Green LED - Sufficient light



Red LED - Insufficient light

1. To turn on the flash, press the Flash button, and you will see the flash icon appear in the status LCD.
2. The flash icon will blink for 5 seconds, and then stabilize.
3. Once the icon stops blinking, the camera is ready to take a picture.
4. Follow the procedure described above to take a picture.

Important Notes About Auto Flash

- The flash will yield best performance at a distance of 3 to 9 feet (1-3 meters) between the camera and the subject. The subject may be over exposed if you stand less than 3 feet (1 meter) to your subject.

Important Notes for Taking Pictures

- Please make sure that your fingers or the strap do not obscure the lens when taking a picture.
- Ensure that the lens is clean; refer to "Camera Maintenance" for cleaning instructions.
- Hold the camera steady as you take a picture to avoid blurry images.

Taking Picture with the Self-timer

You can set up the StyleCam Deluxe with the 10-second self-timer so that you can appear in the photo. The resolution level for self-timer mode is fixed at two stars only. Please follow the instructions below to take a picture with the self-timer.

1. Power on your StyleCam Deluxe by pressing the Power/Mode button.
2. Press the Power/Mode button to scroll to self-timer mode (the self-timer icon should appear in the status display).
3. Find your subject through the viewfinder; place your StyleCam Deluxe on a flat and steady surface.
4. Press the shutter button once, and the camera will start beeping. You have 10 seconds to position yourself before the camera takes a picture.

Note: The StyleCam Deluxe can only take pictures with the self-timer in two-stars resolution mode.

How to Delete Pictures

The StyleCam Deluxe allows you to delete the LAST image saved on your digital camera or

ALL images saved on your digital camera. Please follow the instructions below to erase the pictures.

Deleting Single (LAST) image

1. Power on the StyleCam Deluxe by pressing Power/Mode button.
2. Select the resolution mode of the picture that you want to erase using the Power/Mode button.
3. To erase the LAST picture saved on that mode, press the DELETE button ONCE.
4. You will hear a single beep to confirm that the picture has been erased.
5. Scroll to the other modes to delete single image (or a video clip) by repeating the above steps.

Deleting ALL images

1. To erase ALL of the pictures and ALL videos saved on the StyleCam Deluxe, press and hold down the DELETE button for 5 seconds.
2. You will hear two (2) consecutive beeps, confirming that all pictures and videos have been erased.

Note: Pressing and holding the DELETE button down for 5 seconds will erase everything saved on your StyleCam Deluxe, this is the same as formatting your camera's internal memory.

Recording Movie with the Video & Audio Mode

You can record a movie clip up to 60 seconds in AVI format with your StyleCam Deluxe. The video mode has a resolution of 320×240. Please follow the instructions below to capture a video.

1. Power on your StyleCam Deluxe by pressing the Power/Mode button.
2. Press the Power/Mode button and scroll through the menu until the video icon & the audio icon appear together in the status LCD.
3. Find your subject through the viewfinder; press and hold down the Shutter button to start recording. (*Note:* The total length can be up to 60 seconds, depending on the memory remaining on your StyleCam Deluxe camera). Both video and audio will be recorded simultaneously.
4. You can stop recording by releasing the Shutter button. Or, when the memory becomes full, the StyleCam Deluxe will automatically stop recording.

Note: When the memory is full, the USB icon and the image counter will blink to remind you to transfer your pictures to your computer.

How to Record Voice Annotation

The StyleCam Deluxe allows you to record up to 50 minutes of voice annotation. Please follow the instructions below to record audio.

1. To record only voice annotation without the video, simply select the Audio mode (audio icon alone without video icon showing the status display) using the Power/Mode button.
2. Press the Shutter button to begin recording.
3. Speak into the microphone located on the front of your StyleCam Deluxe.
Note: You do not need to press and hold the Shutter button to keep recording voice. Simply press the Shutter button once to begin recording.
4. To finish recording, press the Shutter button again.

Note: If you already have pictures or videos saved on the StyleCam Deluxe, the audio capacity may vary.

Downloading Still Image & Video


Once you've installed the StyleCam Deluxe TWAIN driver, you can download the images from your digital camera to your computer.

Transfer Images & Video With the StyleCam Deluxe Camera Wizard

You can use the StyleCam Deluxe Camera Wizard to transfer & save, view a slideshow of pictures, play your video, or open folders to view files. Connect the StyleCam Deluxe with the supplied USB cable to your PC; the following screen will appear. *(If the Camera Wizard screen does not appear, please go to the bottom of your computer screen and locate the SiPix Camera Wizard icon on the right-hand side of the task bar. Double-click on the icon (which looks like a camera) to open SiPix Camera Wizard).*



To transfer and save the images and video to your computer, select the first option from the window above "Copy pictures to a folder on my computer" and click OK. The following screen will appear:



Your picture(s) will appear in thumbnail format and the video(s) will display as video icons as

shown in the above screen capture. To save these files to your desired location, click on "Browse", select a location to save your files, and click OK. Your pictures and/or video will be saved under this location.

You can also view your pictures in a slideshow. Chose "View slideshow of the images" from the StyleCam Deluxe Camera Wizard, and click OK.

To play a video, select the video icon from the Camera Wizard, and click OK. Your video will now play in Windows Media Player.

The "Open folder to view files" option lets you view your images and video that are saved on the StyleCam Deluxe. The files will appear either in a list of file names or in picture thumbnail and video icons, depending on the Operating System that you use.

Transfer Images with ArcSoft PhotoImpression

Please follow the instructions below to transfer the pictures using ArcSoft PhotoImpression.

1. Connect the StyleCam Deluxe to your computer (refer to Connecting to Computer from above).
2. Launch the ArcSoft PhotoImpression application via Start → Programs → ArcSoft PhotoImpression → PhotoImpression 3.0.
3. Select "Get Photos" from the top of the left panel.
4. Click on "Camera/Scanner" button located on the bottom of the screen.
5. From the "Select Source" drop-down menu, a list of devices will be displayed. Select "StyleCam Deluxe Camera".
6. Click on the "Acquire" button, and the TWAIN driver screen will acquire the images saved on your camera.
7. The SiPix TWAIN allows you to view each individual image saved on your camera. You can use the arrow keys to scroll to the previous or the next picture. Click the "Transfer" button to download the images to your computer.

Save Images using ArcSoft PhotoImpression

Once you have downloaded (transferred) all the images you want onto your computer. Follow the instructions below to save your pictures on the computer.

1. Click the "Save" button on the left panel of the screen, and then click the "Save As" button in the lower screen.
2. When the Save window opens, select a directory where you want to save your pictures and type in a name for the image file, and click "Save".

Transfer and Save Video Using MY CAMERA

You can also use the "My Camera" feature to save the video clips to your computer. Please follow the instructions below:

1. Go to My Computer → My Camera
2. Your video(s) appear in this folder.
3. Right click on the video icon(s), and select “Copy”.
4. Go to the location you desire, right click on your mouse to bring up a menu, and select “Paste” to copy the video onto your desired location.

Using the StyleCam Deluxe as PC-Camera with ArcSoft VideoImpression

You can use the StyleCam Deluxe with the VideoImpression software to capture and record live video, and then send it to your friends and family. Please follow the instructions below to capture video with ArcSoft VideoImpression.

1. Connect the StyleCam Deluxe to your computer with the supplied USB cable.
2. The camera will power on automatically.
3. Launch ArcSoft VideoImpression. Go to Start → Programs → ArcSoft VideoImpression → VideoImpression 1.6.
4. Click on “New” and then click on “Capture”
5. When the CAPTURE screen appears, it will capture live video, click “Record” button to begin recording your video. Click the “Stop” button to stop recording anytime.

For more information on ArcSoft PhotoImpression and VideoImpression, please visit ArcSoft website at www.arcsoft.com

Saving Video Clips with Windows Media Player

If your computer comes with Windows Media Player (Windows 2000, Me, and XP). You can view your video through Media Player and save the video clips. Please follow the instructions below to save your video:

1. Go to File → Save As (from top left of the menu bar)
2. The Save As screen appears, select a location to save your video, name your file, type in the extension “.AVI”, and click OK.
3. Your video is now saved on your computer.

Note: If you need to install the latest version of Windows Media Player 7.1, please download Media Player free of charge from Microsoft website at <http://www.microsoft.com/windows/windowsmedia/download/default.asp>

For any question on Windows Media Player, please contact Microsoft technical support directly.

Uninstalling Software

You can uninstall the software using “Add/Remove Program” in the **Control Panel** of your computer.

Note: Use this procedure only when the installed software is no longer required or when software installation fails.

Please follow the steps below to uninstall your software.

1. Click to open “My Computer” from your desktop screen.
2. Double click on the “Control Panel” icon.
3. Double click on the “Add/Remove Programs” icon in the Control Panel.
4. The “Add/Remove Programs” property window will appear, select the program that you want to uninstall, and click on the “Add/Remove” button.
5. Your computer will prompt you to confirm whether or not you want to uninstall the software, click “Yes” to confirm. Follow the on screen instruction to complete un-installation.

You may need to restart your computer after uninstalling the software. Please save and close all running programs before you reboot your computer.

Camera Maintenance

Please read the following information to ensure that you use your StyleCam Deluxe correctly.

Places to Avoid

Do not store or use the camera in the following types of locations:

- Very humid, dirty or dusty places
- In direct sunlight or in places subject to extreme temperature, such as in a closed car in summer.
- Extremely cold places
- Places subject to strong vibrations
- Places affected by smoke or steam
- Places subject to strong magnetic fields (such as places near motors, transformers or magnets)
- For long periods in contact with chemicals such as pesticides or next to rubber or vinyl products
- Do not use the camera outdoors if it is raining or snowing

Do Not Expose the StyleCam Deluxe to Sand

The StyleCam Deluxe is particularly and adversely affected by sand. In sandy locations such as beaches or deserts, or in locations where there is wind-borne sand, please make sure that the camera is not exposed to sand.

When the Camera is Unused for Long Period of Time

If you do not intend to use the camera for a period of time, remove the batteries before storing the camera.

Cleaning Your StyleCam Deluxe

Use a small brush and gently remove dust from the lens and LCD surface. Wipe the surface lightly with a soft, lint-free and dry cloth. If any soiling remains, apply a small amount of lens cleaning liquid to a piece lens cleaning paper and wipe gently. Do not touch the lens with the fingers. Do not scratch any part of the camera with hard objects. Clean the body of the camera with a soft dry cloth. Do not use volatile substances such as thinners, benzene or insecticide, as these may react with camera body and cause deformation or remove the coating.

When Traveling Overseas

Do not place your camera in the check-in baggage. Baggage handling at airports may subject baggage to violent shocks, and the camera may be damaged internally even when no external damage is visible.

Camera Repair

If you discover a problem with your StyleCam Deluxe, please contact Technical Support for more information. Do not open the camera case or attempt your own repairs. It will create risk of electrical shock. It will void warranty.

Troubleshooting

If you encounter any hardware or software problem with your StyleCam Deluxe, please refer to the troubleshooting list below to find a possible solution.

Symptoms	Problems	Solution
All the images I have taken do not appear on the StyleCam Deluxe	The StyleCam Deluxe may have lost all power by:	
	1. Insufficient battery power	Upload all images to yours PC as soon as possible.
	2. Removing the battery without being connected to your PC (turned on) via the USB cable.	If you need to change batteries, and retain the images in your StyleCam Deluxe memory, make sure you are connected to a PC, which is turned on via the USB cable. The StyleCam Deluxe is BUS-powered, so it will draw power from your PC.
I cannot upload images to the PC.	Connection failure.	Check to ensure that all connections are secured.
My computer cannot detect the StyleCam Deluxe	USB connection failure	Use the USB Doctor program provided by the StyleCam Deluxe. Insert the CD into your CD-ROM drive, go to My Computers → D:\ (Where "D:\\" is your CD-ROM drive). Open "Utilities" folder and double click on <i>USB Doctor</i> program. Follow the on-screen instruction to use the program.

My CD installation wizard does not work.	The auto installation file is switched to off. Or the CD-ROM is disconnected.	Go to your computer desktop, and right-click on "My Computer". Select "Properties" → "Device Manager". Double click on "CD-ROM", and then double click on "CD-R". Click on "Setting", make sure "Auto insert notification" is checked and the "Disconnect" is checked. If you change the settings the computer will ask you to restart your PC. Click "Yes "
The image counter on the LCD is flashing after I took my last image.	The StyleCam Deluxe is processing the image.	Wait for the image counter to stop flashing and then take your next image. You may need to wait a further 20 seconds before taking the next image.
I get a blurred image when uploading my images to my computer.	There may be a momentary delay between pressing the shutter button and the actual exposure.	Hold your StyleCam Deluxe steady until you hear a "beep" which indicates the exposure is completed.
I press the shutter button and there is no response.	The click-to-click time is between 2 - 5 seconds depending on whether or not the flash is enabled.	Please wait for the camera to refocus when taking pictures consecutively.
Found error in software installation.	If your computer already has some of the programs installed, the automatic installation may have caused some error.	Please install the software again selecting "Custom" Installation.
My StyleCam Deluxe camera cannot power-on after inserting fresh batteries.	The camera may not power up immediately if you exceed one (1) minute to change the batteries.	Reset the camera by pressing the RESET button ONCE with a paper clip inserted into the reset access located on the battery door. Wait for the green LED light to flash, and then the camera will function normally.

Product Specification

SiPix StyleCam Deluxe	
Image sensor	1280 x 1024 CMOS sensor
Image resolution	Still picture: 1280 x 1024, 640 x 512 Movie: 320 x 240
Internal memory	16MB SDRAM
Image capacity (Based on 16MB SDRAM)	Superfine: 9 Images (Approx. only) Fine: 32 Images (Approx. only) Economy: 144 Images (Approx. only) Movie: ~1 minute (Approx. only) Audio: ~ 50 minutes (Approx. only)
Viewfinder	Optical, built-in reverse Galilean filter
Status LCD	Monochrome
Flash	Built-in, Auto/Off
Flash light	Angle: 45 degree, effective: 1-3.5 meters
Lens	5 elements glass lens with IR filter glass
Lens aperture	F3.0
Focus range	59" ~ infinity (1.5m – infinity)
Sensitivity	ISO 75
White balance	Auto
Exposure	Auto exposure
File format	Still: JPG Video: AVI Audio: WAV
Self-timer	10 seconds
Power source	2 x AA alkaline batteries USB BUS-powered
Auto power-off	Stand by mode (After 30 seconds inactivity using batteries)
Computer interface	USB v1.1
Camera dimension	2.7" x 3.96" x 1.06" (69.1 x 100.5 x 26.9 mm)
Camera weight	3.1 oz. (97.2g) not including batteries

Engineering Specification – StyleCam Deluxe

Camera Power up time	2 seconds
Click-to-click time	2.8 seconds
Current of:	
Video recording	240 mA
Still picture	320 mA
Battery life	1000 mAh
Battery life for video recording	4.16 hrs
Battery life for still picture (shooting continuously)	3.12 hrs
Battery life for still picture (shooting continuously with flash)	25-30 images

One Year Limited Warranty – USA & Canada

SiPix, a Foxlink Peripherals, Inc. brand, warrants this hardware product against defects in material and workmanship for a period of one year from the original date of purchase as identified on the proof of purchase (your receipt). It is the end-user's responsibility to make certain this product is in working condition with the intended computer system within the one-year warranty period.

These are the sole remedies and SiPix's sole liabilities for performance or failure to perform of the product. SiPix reserves the right to change its warranty policy at any time for all products distributed after the date of such change in warranty. Except as set forth above, all other warranties whether express or implied, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose are hereby excluded.

SiPix shall not be liable for incidental, special or consequential damages arising out of or related to the use or performance of the product, including, without limitation, loss of data or use of data processing facilities or equipment, regardless of whether SiPix may have been advised about the possibility of such damages arising out of use of the product shall be limited to the amounts paid by purchaser for such product.

This warranty is only valid within the boundaries and territories of the USA and Canada. SiPix is not responsible for costs incurred due to shipping, insurance, customs, or duties. SiPix is not responsible for non-traceable packages or packages shipped without a valid RMA number on the outside of the package.

This warranty does not apply if the product has been damaged by an accident, electrical fault, through misuse or abuse. If the product has been altered without written authorization from SiPix, the warranty will be void.

This warranty applies only to hardware products manufactured by or for SiPix. Warranted products must bear the "SiPix" brand name, trade name, or logo. The aforementioned warranty and remedies are exclusive, and in lieu of all others, whether oral, written, expressed or implied. SiPix specifically disclaims any and all implied warranties of merchantability and fitness for a particular purpose.

SiPix is not responsible for incidental or consequential damages resulting from any breach of warranty. SiPix is not responsible under any other legal theory, including, but not limited to lost profits, and any cost of recovering reprogramming or reproducing any program or data stored in or used with SiPix products.

Warranty Service – USA & Canada

If your SiPix product needs to be returned for repair, you must contact SiPix technical support prior to shipment for an RMA number before sending in the product. **The RMA number is a Return Merchandise Authorization number. SiPix will refuse all shipments without a proper RMA number.** The RMA number **MUST** be printed on the outside of the original shipping carton in large print written in black ink next to the shipping label. Failure to properly pack shipment could cause serious damage to the product and void the warranty.

Should any defect(s) be discovered, the product may be returned to SiPix with a valid RMA number. If you are returning product for repair, please be sure to do the following:

1. Call SiPix Customer Support Mon-Fri during regular business hours at 510.651.9199 and obtain an RMA (Return Merchandise Authorization) number.
2. Print your RMA number on the OUTSIDE of the original shipping carton in large print written in black ink next to the shipping label.
3. Include a copy of the bill of sale with the returned product.
4. Unless otherwise instructed, do not return any manuals or software when returning items for repair.
5. Ship to SiPix via a traceable shipping method and retain the tracking number.

Note: This product is intended for use only within the boundaries and territories of the United States and Canada. If you purchased this product in Mexico or South America and need assistance or repair, you must contact your originating reseller for service and support. SiPix, Fremont CA, will not accept any shipments from outside the boundaries and territories of the USA and Canada. SiPix often bundles many different third party software options with its products. If any of these options were ordered with your SiPix product and they appear to be missing or incorrect, contact your reseller immediately.

Technical Support – USA & Canada

SiPix provides technical support at no cost during the one-year warranty period. Users with questions or concerns of a technical nature should first refer to the product manual, as usage and troubleshooting information is provided in detail. For additional information or assistance, users should visit the SiPix Web-site, as tutorials, updated drivers, frequently asked questions and news updates are available. www.sipixdigital.com/support

Should you require further assistance, you may contact SiPix technical support representatives by calling 510.651.9199.

SiPix Technical Support is available from 8 AM to 6 PM PST, Monday through Friday, excluding holidays.

Technical Support & Warranty - EUROPE

Technical Support

SiPix provides technical support at no cost during the two-year European warranty period. Users with questions or concerns of a technical nature should first refer to the product manual, as usage and troubleshooting information is provided in detail. For additional information or assistance, users should visit the SiPix Web-site, as tutorials, updated drivers, frequently asked questions and news updates are available at www.sipixdigital.com/support

Should you require further assistance, you may contact SiPix technical support representatives by calling:

For free Technical Support call in Europe*: **00800-800 SiPix** (00800-80074749) or by E-Mail : sipix@appello.de. SiPix Technical Support is available from 9 AM to 6 PM CET, Monday through Friday, excluding public holidays.

Technische Unterstützung

SiPix bietet kostenlose technische Unterstützung innerhalb der zweijährigen Europäischen Garantiefrist. Wenn Sie technische Fragen haben, sollten Sie zuerst das Benutzerhandbuch lesen, da sich detaillierte Informationen zur Verwendung und Fehlerbehebung in dem Benutzerhandbuch befinden. Für zusätzliche Informationen oder Unterstützung besuchen Sie bitte die SiPix Web-Site, wo Lehrgänge, aktuelle Treiber, häufig gestellte Fragen und Update-Programme angeboten werden. www.sipixdigital.com/support

Sie können ebenfalls Kontakt mit dem Team unserer technischen Unterstützung aufnehmen, um weitere Hilfe zu erhalten:

Gebührenfreie technischen Hotline in Europa* : **00800-800 SiPix** (00800-80074749) oder per E-Mail : sipix@appello.de.

Unsere technische Unterstützung steht Ihnen von Montag bis Freitag von 9 Uhr bis 18 Uhr Mitteleuropäischer Zeit ausschließlich Feiertagen zur Verfügung.

Support Technique

SiPix fournit le support technique sans frais pendant la période de garantie d' deux ans. Les utilisateurs qui se posent des questions de nature technique doivent se référer tout d'abord au Manuel Utilisateur, car les informations relatives à l'utilisation et au dépannage sont présentées en détail. Pour les informations supplémentaires ou l'aide, les utilisateurs peuvent visiter le site web de SiPix www.sipixdigital.com/support , car il met à leur disposition des tutoriaux, des pilotes mis à jour, des questions fréquemment posées et des mis à jour d'informations.

Si vous avez besoin de plus d'aide, vous pouvez contacter les représentants du support technique SiPix en appelant:

Pour assistance Technique rappeler le numéro gratuit en Europe* : **00800-800 SiPix** (00800-80074749) ou par E-Mail : sipix@appello.de

Le Support Technique de SiPix est disponible de 9h à 18h, du lundi au vendredi, sauf les jours fériés.

TEL: 00800-800 SiPix

*Finland, Norway, Sweden, Denmark, Austria, Belgium, The Netherlands, Luxembourg, France, Switzerland, Italy, UK, Ireland, Germany. In the **UK** you can use as well **0845 6604550**

FOXLINK EUROPE B.V., SPUIKADE 3, 3087 BG ROTTERDAM, THE NETHERLANDS

Technical Support & Warranty – ASIA PACIFIC

Technical Support

Upon receipt of this SiPix product you are immediately eligible for Technical Support during the warranty period of ONE YEAR from the purchase date. For technical support please call 886-2-8226-9298.